

Product information according to Regulation (EU) 2023/826

Product: Food processor

Trade mark: Bosch

Model identifier: MC812S734G

Condition	Max. Power consumption (W)	Max. Period auto activation power management function (minutes)
Power consumption off	-	-
Power consumption of the appliance in another state in which the applicable requirements for power consumption in the off state or standby state are not exceeded when the appliance is connected to the mains supply.	-	-
Power consumption standby/display off	-	-
Power consumption standby/display on	-	-
Power consumption standby/network: Please check the user manual for how to switch off the WiFi module.	-	-
Networked standby if all wired network ports are connected and all wireless network ports are activated	-	--
Activation and deactivation of wireless network ports	For models with wireless connections, you can save energy by disconnecting the network ports when not in use. More information can be found in the User Manual	