

Product information according to Regulation (EU) 2023/826

Product: Toaster
Trade mark: Bosch
Model identifier: TAT4P447GB

Condition	Max. Power consumption (W)	Max. Period auto activation power management function (minutes)
off mode	0.0	0.0
Low Power Mode	-	-
Power consumption standby/display off	-	-
Power consumption standby/display on	-	-
Power consumption standby/network: Please check the user manual for how to switch off the WiFi module.	-	-
Networked standby if all wired network ports are connected and all wireless network ports are activated	-	--
Activation and deactivation of wireless network ports	For models with wireless connections, you can save energy by disconnecting the network ports when not in use. More information can be found in the User Manual	